

How to Set Up WIFI on the FD150 Terminal (Step-by-Step Guide)

Setting up your FD150 credit card terminal to connect to WIFI is essential for reliable payment processing. Whether you're switching from Ethernet to wireless or setting up a new location, this guide will walk you through each step of the FD150 WIFI setup process.

At Monify Merchant Solutions, we help business owners get the most out of their payment technology with tools that are easy to use, secure, and built to keep transactions flowing.

FD150 WIFI Setup Instructions

1. Access WIFI Settings

- Press the orange toolbar in the top-right corner of the main screen
(If you're in the Lodging App, press 0 Setup WIFI)

2. Set Connection Mode (DHCP or Static)

- Tap WIFI
- Tap Set Mode
- DHCP Users: Select DHCP, then tap Save
- Static IP Users: Select Static, then tap Save
- Tap Set IP Address and input:
 - IP Address
 - Subnet Mask
 - Gateway
 - DNS
- Press the Red key once to go back

3. Enter WIFI Security Settings

- Tap Security
- Enter your system password:
 - For Nashville users: Nashville- + last 4 digits of your Nashville MID
 - For Bypass users: Use 123456

Tip: If you have a USB keyboard, connect it to the back of the terminal to make data entry easier.

4. Select WIFI Security Type

In the Security Drop Box, select the appropriate encryption protocol:

- WEP
- WPA1-TKIP
- WPA1-AES
- WPA2-AES (recommended)

5. Enter Network Details

- KEY: Your WIFI password (case-sensitive)
- SSID: Your network name (case-sensitive)
- Press the Green Enter button

6. Reboot the Terminal

When prompted with "Apply Settings and Reboot?" Select Yes

How to Confirm WIFI Is Working

After reboot:

1. Go to Orange Toolbar WIFI Ping
2. Type in: yahoo.com
3. Press Green Enter
4. Review the results:
 - If it returns numbers, the connection is working
 - If it says NONE, double-check your WIFI settings (SSID, password, encryption type)

Special Character Entry Tips for the FD150 Keypad

Use the following shortcuts to enter case-sensitive and special characters on the terminal:

- Switch Case: Hold Green + press Alpha, release
- Dash (-): Green + 1
- Underscore (_): Alpha 4x, then press 5
- Space: Alpha 1x, then press 1
- Equal Sign (=): Alpha 4x, then press 6
- Dollar Sign (\$): Alpha 4x, then press 2
- Ampersand (&): Alpha 4x, then press 4

Pro Tip: Practice the keypad entry with non-sensitive data before setting up your real WIFI connection.

Need Help? Weve Got You Covered

At Monify Merchant Solutions, we offer 24/7 support and in-person assistance across the U.S. If youre having trouble getting your FD150 terminal online or need help with another device, our certified payment professionals are ready to assist.

Contact us today or schedule a consultation with one of our experts.

Additional Enhancements for This Blog Post

SEO Optimization

- Target Keywords:
- FD150 WIFI setup
- how to connect FD150 to WIFI
- FD150 terminal setup guide

- FD150 wireless connection

- Meta Description:

Learn how to set up your FD150 terminal to WIFI in minutes. Step-by-step setup guide with tips, shortcuts, and troubleshooting help from Monify Merchant Solutions.

- Structured Data Markup: Add FAQ schema for:

- How do I enter special characters on the FD150?

- How do I ping a website on the FD150?

- What WIFI security setting should I use?

Visual Enhancements

- Image Suggestions:

- FD150 main screen with orange toolbar highlighted

- Example of WIFI settings screen

- Table diagram of keypad and character entry shortcuts

- Use icons () to enhance scan-ability

Suggested Related Posts

- How to Set Up Clover POS with WIFI

- Troubleshooting Payment Terminal Errors

- Choosing the Best Payment Processing Setup for Your Business

Offer a Downloadable Version

- Create a print-ready PDF of this guide for staff or technicians

- Include a QR code on printed versions that links back to the online article